

RASPBERRY PI I/O EXPANSION CARD

for BUILDING AUTOMATION

USER'S GUIDE VERSION 1.0

GENERAL DESCRIPTION..... 2

BOARD LAYOUT..... 3

RS-485/MODBUS COMMUNICATION 4

STACK LEVEL..... 5

RASPBERRY PI HEADER..... 6

POWER REQUIREMENTS 7

SCHEMATICS 8

HARDWARE WATCHDOG 10

ANALOG INPUTS/OUTPUTS CALIBRATION..... 11


HARDWARE SPECIFICATIONS 12

LINEARITY OVER FULL SCALE..... 13

MECHANICAL SPECIFICATIONS 14

SOFTWARE SETUP 15

GENERAL DESCRIPTION



The second generation of our Building Automation card brings to the Raspberry Pi platform all the building blocks required for Building Automation projects. Stackable to 8 levels, the card works with all Raspberry Pi versions, from Zero to 4.

Two of the Raspberry Pi's GPIO pins are used for I2C communication. Another pin is allocated for the interrupt handler, leaving 23 GPIO pins available for the user.


FEATURES at a glance:

- Eight jumper settable universal, analog/digital inputs
 - 0-10V Inputs or
 - Contact closure/counter inputs or
 - 1K/10K temperature sensor inputs
- Four 0-10V Outputs
- Four TRIAC Outputs with 1A/48VAC drivers
- Four General Purpose LED's
- RS485 in and out ports
- Real time clock with battery backup
- On-board push-button
- Hardware Watchdog
- 24VAC/DC power supply




All inputs and output use pluggable connectors which permit easy wiring access when multiple cards are stacked.

The four general purpose LED's can be associated with the analog inputs or other controlled processes.




The on-board push button can be programmed to cut inputs or override outputs.

BOARD LAYOUT



RS-485/MODBUS COMMUNICATION

The MEGA-BAS card contains a standard RS485 transceiver which can be accessed both by the local processor and by Raspberry Pi. The desired configuration is set from three bypass jumpers on configuration connector J3.



If jumpers are installed, Raspberry Pi can communicate with any device with an RS485 interface. In this configuration the MEGA-BAS card is a passive bridge which implements only the hardware levels required by the RS485 protocol.



If jumpers are removed, the card operates as MODBUS slave and implements the MODBUS RTU protocol. Any MODBUS master can access all the card's inputs, and set all the outputs using standard MODBUS commands. A detailed list of commands implemented can be found on GitHub:

<https://github.com/SequentMicrosystems/megabas-rpi/blob/master/Modbus.md>


In both configurations the local processor needs to be programmed to release (jumpers installed) or control (jumpers removed) the RS485 signals. See the command line online help for further information.

STACK LEVEL

The left three position of the J3 connector are used to select the stack level of the card:




RASPBERRY PI HEADER



POWER REQUIREMENTS

The MEGA-BAS card requires an external 24VDC/AC regulated power supply. Power is supplied to the board through the dedicated connector in the upper right corner (see BOARD LAYOUT). The boards accepts either DC or AC power source. If a DC power source is used, polarity is not important.



A local 5V regulator supplies up to 3A power to Raspberry Pi, and a 3.3V regulator powers the digital circuits. Isolated DC-DC converters are used to power the relays.


**WE RECOMMEND USING ONLY THE 24VDC/AC POWER SUPPLY
TO POWER THE RASPBERRY PI CARD**

If multiple MEGA-BAS cards are stacked on top of each other, we recommend using a single 24VDC/AC power supply to power all the cards. The user must split the cable and run the wires to each MEGA-BAS card.


POWER CONSUMPTION:

- 50 mA @ +24V (all relays OFF)
- 150 mA @ +24V (all relays ON)


SCHEMATICS




0-10V INPUTS



0-10V OUTPUTS



UNIVERSAL INPUTS



TRIAC OUTPUTS

HARDWARE WATCHDOG

The MEGA-BAS card contains a built-in hardware watchdog which will guarantee that your mission-critical project will continue running even if Raspberry Pi software hangs up. After power up the watchdog is disabled, and becomes active after it receives the first reset.

The default timeout is 120 seconds. Once activated, if it does not receive a reset from Raspberry Pi within 2 minutes, the watchdog cuts the power and restores it after 10 seconds.

Raspberry Pi needs to issue a reset command before the timer on the watchdog expires. The command can be sent either on the I2C port, or by toggling GPIO13 (Pin 33 on the GPIO connector). The timer period after power up and the active timer period can be set from the command line. The number of resets is stored in flash and can be accessed or cleared from the command line. All the watchdog commands are described by the online help function.

ANALOG INPUTS/OUTPUTS CALIBRATION

All the analog inputs and outputs are calibrated at the factory, but firmware commands permit the user to re-calibrate the board, or to calibrate it to better precision. All inputs and outputs are calibrated in two points; select the two points as close to possible to the two ends of scale. To calibrate the inputs, the user must provide analog signals. (Example: to calibrate 0-10V inputs, the user must provide a 10V adjustable power supply). To calibrate the outputs, the user must issue a command to set the output to a desired value, measure the result and issue the calibration command to store the value.

The values are stored in flash and the input curve is assumed to be linear. If a mistake is made during calibration by typing the wrong command, a RESET command can be used to reset all the channels in the corresponding group to factory values. After RESET calibration can be restarted.

The board can be calibrated without a source of analog signals, by calibrating first the outputs and then routing the calibrated outputs to corresponding inputs. The following commands are available for calibration:

CALIBRATE 0-10V INPUTS:	megabas<id> cuin <channel> <value>
RESET CALIBRATION OF 0-10V INPUTS:	megabas<id> rcuin
CALIBRATE 10K INPUTS:	megabas<id> cresin <channel> <value>
RESET 10K INPUTS:	megabas<id> rcresin
CALIBRATE 0-10V OUTPUTS:	megabas<id> cuout <channel> <value>
RESET CALIBRATION OF 0-10V OUTPUTS:	megabas<id> rcuout

HARDWARE SPECIFICATIONS

ON BOARD FUSE: 1A

0-10V INPUTS:

- Maximum Input Voltage: 12V
- Input Impedance: 20K Ω

0-10V OUTPUTS:

- Minimum Output Load: 1K Ω

TRIAC OUTPUTS:

- Maximum Output Current: 1A
- Maximum Output Voltage: 120V

LINEARITY OVER FULL SCALE

Analog inputs are processed using 12 bit A/D converters internal to the on-board processor. The inputs are sampled at 675 Hz.


Analog outputs are PWM synthesized using 16 bit timers. PWM values range from 0 to 4,800.

All inputs and outputs are calibrated at test time at the end points and values are stored in flash.

After calibration we checked the linearity over full scale and obtained the following results:

Channel	Max Error	%
0-10V IN	15 μ V	0.15%
0-10V OUT	10 μ V	0.1%

MECHANICAL SPECIFICATIONS



SOFTWARE SETUP

1. Have your Raspberry Pi ready with the [latest OS](#).

2. Enable I2C communication:

```
~$ sudo raspi-config
```

1. Change User Password	Change password for default user	
2. Network Options	Configure network settings	
3. Boot Options	Configure options for start-up	
4. Localisation Options	Set up language and regional settings to match..	
5. Interfacing Options	Configure connections to peripherals	
6. Overclock	Configure overclocking for your Pi	
7. Advanced Options	Configure advanced settings	
8. Update	Update this tool to the latest version	
9. About raspi-config	Information about this configuration	
P1	Camera	Enable/Disable connection to the Raspberry Pi Camera
P2	SSH	Enable/Disable remote command line access to your Pi
P3	VNC	Enable/Disable graphical remote access to your Pi using...
P4	SPI	Enable/Disable automatic loading of SPI kernel module
P5	I2C	Enable/Disable automatic loading of I2C kernel module
P6	Serial	Enable/Disable shell and kernel messages to the serial port
P7	1-Wire	Enable/Disable one-wire interface
P8	Remote GPIO	Enable/Disable remote access to GPIO pins

3. Install the megabas software from github.com:

```
~$ git clone https://github.com/SequentMicrosystems/megabas-rpi.git
```

4.

```
~$ cd /home/pi/megabas-rpi
```

5.

```
~/megaioind-rpi$ sudo make install
```

6.

```
~/megaioind-rpi$ megabas
```

The program will respond with a list of available commands.

Type "`megabas -h`" for online help.

After installing the software, you can update it to the latest version with the commands:

```
~$ cd /home/pi/megabas-rpi
```

```
~/megabas-rpi$ git pull
```

```
~/megabas-rpi$ sudo make install
```

